




Picnic Table

➤ Installation and Operational Instructions



Product code: RPTB/RPTW




Dimensions (mm):	800*450*25
Weight (kg):	5.1
Load capacity (kg):	30
Color	Black/White
Power (W):	2.4

Picnic Table Installation Instructions

Step 1: Fix the picnic table frame to the wall with M4 self-drilling screws;

(Note: The specific length of the screw is configured according to the thickness of the wall board. Please be careful not to punch through the wall board when using the screw.)




Step 2: Secure the lining plate on the picnic table frame

(Note: The lining plate is recommended to cover screw holes and exposed wall panels)

Lining plate


Remove the cover of the 3M double-sided tape on the back of the liner;
Then place the lining plate to the specified position of the outer frame.




Usage

Latch:

The latch needs to be pulled downwards to unfold and fold the product.



LED switch



Pull upwards when folding up the table

